


P0550 Save A Drop™ Water Meter



(E) Everytime watering volume

(W) Watering volume accumulation

Your Digital Water Flow Meter comes to you with the battery already installed.

Button A: 1) Resets the top counter (E) to zero

Button B: 1) Resets the bottom counter (W) to zero

The LCD displays will flash once after inserting a new battery, then screen appears as above.
The default measurement is LIT (Litres)

Battery save mode: The screen will fade out in 30 minutes if there is no water flow or no button activation
Also the interval measurement will reset to zero.

To start the counting function from the battery save mode:

- 1) Press button A or B (or both A & B)
- 2) The device will detect any water flow and start to count.

Operation

- 1) When water flow commences, both (E) and (W) will count the flow volume (fig 1).
- 2) To zero (E) reading, press button A. (fig 2).
- 3) (W) reading continues to accumulate water volume (fig 3) until zeroed
- 4) To take both (E) and (W) back to zero press button B.

How to switch measurement (Litre/Gallon)

Press button A for three seconds and release. A black dot will flash in the lower left corner (fig 4).

Select GAL or LIT by pressing the button. B Then press button A to confirm the setting

In this mode, the flow meter counter will revert to the counting function in 30 seconds if no button is pressed.




fig1




fig 2




fig 3




fig 4