



COLOR/WATTAGE SELECTABLE LED CORN BULB – 277-480V

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

WARNING

- Installation, service, and maintenance of luminaires should be performed by a qualified licensed electrician.

CAUTION

- Do not use this LED lamp with an electric generator.
- This device is not intended for use with emergency exits.
- Added weight of this LED lamp may cause instability of a free-standing portable luminaire. Use only with a portable luminaire that utilizes a lens.
- Avoid using this LED lamp in environments where smoke, sulfur, or corrosive substances are present. If being used in these environments, the lamp must be protected by an enclosed compartment with dimensions no less than the sizes listed in the chart below. The compartment lens should be glass, semi-glass, or semi-metallic, and should have no coverings on the surface, such as insulation, that could potentially block heat dissipation.

Maxim Power (W)	50 & 80	120	150	200	270	360	450
Volume (Inches)	16.6x	17.4x	18.5x	18.5x	18.5x	18.5x	18.5x
	8.7x	10.3x	12.6x	12.6x	15.0x	15.0x	15.0x
	8.7	10.3	12.6	12.6	15.0	15.0	15.0


Installation Instructions

1. Turn off power.
2. Unscrew the existing CFL, metal halide, or high-pressure sodium bulb.
3. Disconnect any ballast, capacitor, and ignitor if present. See Wiring Diagram section for more information.
4. Screw in the LED corn lamp (Figures 1, 2, or 3).
5. If a safety cable is provided, attach one end to the LED corn lamp and the other end to a nearby structural support (Figure 3).
6. For horizontal mounting, the 200-450W LED corn lamps are packaged with a support bracket to prevent the lamp and socket from sagging. Attach the bracket to the top end of the corn lamp with the provided screw (Figure 4).
7. Adjust the wattage and CCT to your desired setting using the two sliding switches found near the base of the lamp. See Adjustable CCT and Wattage section for more information.
8. Turn the power back on.




COLOR/WATTAGE SELECTABLE LED CORN BULB – 277-480V


WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS



Wiring Diagram



CCT and Wattage Adjustable



Maximum Rated Wattage	Wattage Selections		
50W	25W	38W	50W
80W	40W	60W	80W
120W	60W	90W	120W
150W	80W	120W	150W
200W	100W	150W	200W
270W	135W	200W	270W
360W	180W	270W	360W
450W	225W	338W	450W

⚠ WARNING

- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- To reduce the risk of death, personal injury, or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards, read all warnings and instructions included with and on the fixture box and all fixture labels.



COLOR/WATTAGE SELECTABLE LED CORN BULB – 277-480V

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

- Proper grounding is required to ensure safety.
- Power must be turned off at the breaker before installation or maintenance.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Wear gloves and eye protection at all times while installing, servicing, or performing maintenance on the luminaire, and avoid direct eye exposure to the light source while it is on.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not install damaged product. Inspect luminaire for damage that may have occurred during transit. If damaged, contact the manufacturer immediately.
- These instructions do not purport to cover all details or variations in equipment nor to provide every possible contingency to meet in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's or owner's purposes, contact the manufacturer.

⚠ ADVERTENCIA

- Antes de instalar, reparar o realizar el mantenimiento de rutina de este equipo, siga estas precauciones generales.
- Para reducir el riesgo de muerte, lesiones personales o daños a la propiedad por fuego, descarga eléctrica, caída de piezas, cortes / abrasiones y otros peligros, lea todas las advertencias y instrucciones incluidas con y en la caja del dispositivo y todas las etiquetas del dispositivo.
- Se requiere una conexión a tierra adecuada para garantizar la seguridad.
- Se debe apagar la energía en el disyuntor antes de la instalación o el mantenimiento.
- Este producto debe ser instalado de acuerdo con el código de instalación aplicable por una persona familiarizada con la construcción y operación del producto y los peligros involucrados.
- Utilice guantes y protección para los ojos en todo momento durante la instalación, el servicio o el mantenimiento de la luminaria, y evite la exposición directa de los ojos a la fuente de luz mientras está encendida.
- Para evitar daños o abrasiones en el cableado, no exponga el cableado a bordes de láminas de metal u otros objetos afilados.
- No instale un producto dañado. Inspeccione la luminaria en busca de daños que puedan haber ocurrido durante el tránsito. Si está dañado, comuníquese con el fabricante de inmediato.
- Estas instrucciones no pretenden cubrir todos los detalles o variaciones en el equipo ni proporcionar todas las posibles contingencias a cumplir en relación con la instalación, operación o mantenimiento. Si desea obtener más información o si surgen problemas particulares que no están suficientemente cubiertos para los propósitos del comprador o propietario, comuníquese con el fabricante.