



# Battery Operated Norfolk Decorative Christmas Greenery

## DESCRIPTION

Get any room or outdoor space ready for the holiday season with these battery-operated Norfolk garlands and wreaths. Accented with real pinecones and life-like juniper berries for a more realistic appearance, this collection of Christmas greenery is pre-lit with warm white LEDs.

## FEATURES

- Designed for indoor and outdoor use
- UV treated to resist fading in the sun; weatherproof
- Accented with real pinecones
- Comes pre-lit with warm white LEDs
- If one bulb burns out, the rest will stay lit
- Uses C batteries (not included)
- Battery box has stainless steel connections and is sealed with a rubber gasket
- Built-in timer feature helps extend battery life; 6 hours ON, 18 hours OFF
- Garlands have bendable center wire that allows for easy shaping

## ELECTRICAL

- Battery Type: C (batteries not included)
- # of Batteries: 3, 6
- Timer: 6 hours ON, 18 hours OFF

## CONSTRUCTION

- Greens made from synthetic and PE
- Berries made from Styrofoam
- Real pinecones

<b>Project name</b>	<b>Type</b>
<b>Catalog number</b>	
<b>Comments</b>	<b>Voltage</b>
<b>Approved by</b>	<b>Date</b>



## APPLICATIONS

- Porches
- Patios
- Entryways
- Doorways
- Mantels
- Columns
- Offices
- Hotels
- Living Spaces
- Floral Arrangements
- Centerpieces

## PERFORMANCE SUMMARY

Item #	Description	Pre-lit	Bulb Type	# of Bulbs	Power	Battery Type	# of Batteries	Timer	# of Tips
PLT-20342	6' Garland	Yes	Warm White LEDs	50	Battery Operated	C	6	6 Hours ON 18 Hours OFF	96
PLT-20343	9' Garland	Yes	Warm White LEDs	76	Battery Operated	C	6	6 Hours ON 18 Hours OFF	142
PLT-20344	24" Wreath	Yes	Warm White LEDs	35	Battery Operated	C	3	6 Hours ON 18 Hours OFF	56
PLT-20345	30" Wreath	Yes	Warm White LEDs	50	Battery Operated	C	3	6 Hours ON 18 Hours OFF	68

## DIMENSIONS

### **PLT-20342**

Length – 6'

### **PLT-20344**

Diameter – 24"

### **PLT-20343**

Length – 9'

### **PLT-20345**

Diameter – 30"

## TIPS

- To shape, gently pull all branches so they are perpendicular from the spine, then using your hands gently “brush” the branches in the same direction in one sweeping motion 3 to 4 times.
- Store in a cool, dry place.
- If the product gets dirty, spray it with water and wipe with a soft cloth. Do not use abrasive detergents.
- When not in use, remove batteries and close and latch the battery box.