



COLOR/WATTAGE/BEAM ANGLE SELECTABLE LED FLOOD LIGHT FIXTURE

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

WARNING

- Installation, service, and maintenance of luminaries should be performed by a qualified licensed electrician.
- Read these instructions carefully before attempting installation.
- Check to make sure none of the components were damaged during shipping and check to make sure all accessories are accounted for. If there are any damaged or missing parts, contact the manufacturer.

CAUTION

- Do not use an electric generator to test this fixture.
- If the wires smoke or spark, turn off power immediately and contact a licensed electrician.
- Operating temperature of supply conductors: -40 to 122°F

Installation Instructions

1. Take the fixture out of the package.
2. Make the wiring connections to the pole according to the wiring diagram, paying close attention to the positive, negative, and ground wires (Figure 1.1 & Wiring Diagram section), then tuck all the wires into the pole (Figure 1.2).
3. To adjust the angle of the fixture using the knuckle mount, loose the screws, set the angle to your desired position, and tighten the screws to lock the angle into place (Figure 1.3).




Figure 1.1




Figure 1.2





Figure 1.3

Wiring Diagram

This LED fixture has 0-10V dimming.

If you opt not to use this feature, cap the purple (Dim+) and pink (Dim-) wires using UL-approved wire nuts.









COLOR/WATTAGE/BEAM ANGLE SELECTABLE LED FLOOD LIGHT FIXTURE

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

CCT, Wattage, and Photocell Adjustment

1. Unscrew the 3/4" metal plug and plastic plug counterclockwise with a screwdriver (Figure 2.1).	 Figure 2.1
2. Slide the three switches up and down to adjust the power, CCT, and photocell per your desired settings (Figure 2.2). Setting Options: ○ Wattage: 15W, 25W, 35W ○ CCT: 3000K, 4000K, 5000K ○ Photocell: On, Off	 Figure 2.2
3. Once the controls have been adjusted to your desired settings (Figure 2.3), tighten the 3/4" metal plug and the 3/4" plastic plug clockwise using a screwdriver (Figure 2.4).	 Figure 2.3  Figure 2.4

Beam Angle Adjustment

1. Locate the beam angle selection tool (provided) and insert it into the center of the dial labeled with beam angle settings (90°, 75°, 55°) (Figure 3.1).
2. Select the desired angle by turning the dial left or right using the tool (Figure 3.2).



Figure 3.1




Figure 3.2



Default Settings

- Wattage: 35W
- CCT: 5000K
- Beam Angle: 90°

⚠ WARNING

- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- To reduce the risk of death, personal injury, or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards, read all warnings and instructions included with and on the fixture box and all fixture labels.
- Proper grounding is required to ensure safety.
- Power must be turned off at the breaker before installation or maintenance.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Wear gloves and eye protection at all times while installing, servicing, or performing maintenance on the luminaire, and avoid direct eye exposure to the light source while it is on.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not install damaged product. Inspect luminaire for damage that may have occurred during transit. If damaged, contact the manufacturer immediately.
- These instructions do not purport to cover all details or variations in equipment nor to provide every possible contingency to meet in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's or owner's purposes, contact the manufacturer.

⚠ ADVERTENCIA

- Antes de instalar, reparar o realizar el mantenimiento de rutina de este equipo, siga estas precauciones generales.
- Para reducir el riesgo de muerte, lesiones personales o daños a la propiedad por fuego, descarga eléctrica, caída de piezas, cortes / abrasiones y otros peligros, lea todas las advertencias y instrucciones incluidas con y en la caja del dispositivo y todas las etiquetas del dispositivo.
- Se requiere una conexión a tierra adecuada para garantizar la seguridad.
- Se debe apagar la energía en el disyuntor antes de la instalación o el mantenimiento.
- Este producto debe ser instalado de acuerdo con el código de instalación aplicable por una persona familiarizada con la construcción y operación del producto y los peligros involucrados.
- Utilice guantes y protección para los ojos en todo momento durante la instalación, el servicio o el mantenimiento de la luminaria, y evite la exposición directa de los ojos a la fuente de luz mientras está encendida.
- Para evitar daños o abrasiones en el cableado, no exponga el cableado a bordes de láminas de metal u otros objetos afilados.
- No instale un producto dañado. Inspeccione la luminaria en busca de daños que puedan haber ocurrido durante el tránsito. Si está dañado, comuníquese con el fabricante de inmediato.



COLOR/WATTAGE/BEAM ANGLE SELECTABLE LED FLOOD LIGHT FIXTURE

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

- Estas instrucciones no pretenden cubrir todos los detalles o variaciones en el equipo ni proporcionar todas las posibles contingencias a cumplir en relación con la instalación, operación o mantenimiento. Si desea obtener más información o si surgen problemas particulares que no están suficientemente cubiertos para los propósitos del comprador o propietario, comuníquese con el fabricante.