

Commercial LED

CLT94 18W T8 Dual Mode Ballast List

Ballast Brand	Model#	Type	QTY of working Lamps	Compatability
ACCUPRO	AP-332IP-UNV-M	Instant Start	3-lamp	YES
	AP-432IP-UNV	Instant Start	4-lamp	YES
ESPEN	VE232MVHIPE	Instant Start	2-lamp	YES
	VE232MVHIPLE	Instant Start	2-lamp	YES
	VE432120HIP	Instant Start	4-lamp	YES
	VE432MVHIPE	Instant Start	4-lamp	YES
	VE432MVHIPLE	Instant Start	4-lamp	YES
GE	GE132MAX-H/ULTRA	Instant Start	1-lamp	YES
	GE232MAX347-N	Instant Start	2-lamp	YES
	GE232MAX-L/ULTRA	Instant Start	2-lamp	YES
	GE232-MVPS-N	Rapid Start	2-lamp	YES
	GE232-N-347	Instant Start	2-lamp	YES
	GE-240-RS-MV-N	Rapid Start	2-lamp	YES
	GE332MAX-N/ULTRA	Instant Start	3-lamp	YES
	GE332-MVPS-N	Rapid Start	3-lamp	YES
	GE432-120RESDIYB	Instant Start	4-lamp	YES
	GE432MAX347-N	Instant Start	4-lamp	YES
	GE432-MVPS-N	Rapid Start	4-lamp	YES
HALCO	EP232IS/L/MV/HE	Instant Start	2-lamp	YES
HOWARD IND.	EP3/32IS/MV/MC/HE	Instant Start	3-lamp	YES
KEYSTONE	KTEB-232RIS-1-TP-SL	Instant Start	2-lamp	YES
	KTEB-232RIS-1-TP-SL/Ga	Instant Start	2-lamp	YES
OSRAM / SYLVANIA	QHE 1X32T8/UNV ISN-SC	Instant Start	1-lamp	YES
	QHE 2X32T8/UNV ISL-SC	Instant Start	2-lamp	YES
	QHE 3X32T8/UNV ISL-SC	Instant Start	3-lamp	YES
	QHE 3X32T8/UNV ISN-SC	Instant Start	3-lamp	YES
	QHE 3X32T8/UNV PSN-SC	Rapid Start	3-lamp	YES
	QHE 4x32T8/347 ISL-SC	Instant Start	4-lamp	YES
	QHE 4X32T8/347 ISN-SC	Instant Start	4-lamp	YES
	QT 2X32 T8/347 ISL-SC	Instant Start	2-lamp	YES
	QT 4X32/120 LP	Instant Start	4-lamp	YES
	QTP 2X32T8/UNV ISN-SC	Instant Start	2-lamp	YES
PACIFIC FLUOR.	EB-232IS-120-RES	Instant Start	2-lamp	YES
PHILIPS / ADVANCE	ICN-2P32-N	Instant Start	2-lamp	YES
	ICN-2S40-N	Instant Start	2-lamp	YES
	ICN-3P32-N	Instant Start	3-lamp	YES

Commercial LED

CLT94 18W T8 Dual Mode Ballast List

Ballast Brand	Model#	Type	QTY of working Lamps	Compatability
PHILIPS / ADVANCE	IOP-3P32-N	Instant Start	3-lamp	YES
	IOP-4P32-LW-N	Instant Start	4-lamp	YES
	IOPA-1P32-N	Instant Start	1-lamp	YES
	IOPA-2P32-LW-N	Instant Start	2-lamp	YES
	IOPA-4P32-LW-N	Instant Start	4-lamp	YES
	IOPA-4P32-N	Instant Start	4-lamp	YES
TRIAD	B232IUNVHP-B	Instant Start	2-lamp	YES
	B232IUNVHP-N	Instant Start	2-lamp	YES
	B332IUNVHP-A	Instant Start	3-lamp	YES
	B432IUNVHP-A	Instant Start	4-lamp	YES
UNIVERSAL	B232IUNVEL-N	Instant Start	2-lamp	YES
	B232IUNVHEH-A	Instant Start	2-lamp	YES
	B332IUNVEL-A	Instant Start	3-lamp	YES
	B332IUNVHE-A	Instant Start	2-lamp	YES
	B332PUNVHE-A	Pulse Start	3-lamp	YES
	B4321UNVEL-A	Instant Start	4-lamp	YES
	B432IUNVHE-A	Instant Start	4-lamp	YES
WORKSHORSE	WH3-120-C			YES
	WH3-120-L			YES
Note: 1. Absence of a ballast from this chart does not imply incompatibility. Please reference the ballast manufacturer's instructions for installation and further information. 2 This list is to be used as a general guideline, the LED tube may not work if the ballast is over 5 years old or have a weak starting voltage. 3. Please use caution and test lamps in fixtures for an extended period of time to ensure proper operation. 4. Do not proceed with a mass installation until proper operation of the LED tube is verified.				